NX - CHANGE OUT SHEET SIZE

SUMMARY:

- CTRL-L (Layer Settings). Change Work Layer from 1 to 199 (or other empty layer) by double-clicking. Shift-Select & turn off layers 1 – 247. Shift-Select and turn on layers 248 – 256.
- Window-select (drag) & delete everything in current sheet.
- 3. Edit Sheet/ select new Sheet size.
- Import Part (Uncheck 'Create Named Group', set Layer to 'Original', Select Part from 'TeamCenter').
- 5. Search for [*noviews*] & choose size. E templates are separated into "Major" (Sheet 1) and "Minor" (Sheets 2, etc.).
- 6. CTRL-L, Change Work Layer to Layer 1. Return Layers to original visibility settings or set visibility as needed. Set 256 to 'Visible Only.'